



slider



Grate position for burning wood + dung  
Light the fire near the chimney end!




Grate position for burning coal -  
Light the fire near the chimney end!

Safed Garmi  
Model 2 A and B  
Version 1.4  
2016-10-08


C Pemberton-Pigott

Dwg. TJ2-1.4-11

Grate Positions



Flame Tube



2 x Corrosion Plates (3mm)  
Weld into the top corner  
to protect the End Plate